
Economy Electric Displacement Stage

α-Axis · External Photoelectric Switch Cross Roller Guide





Model		Photoelectric Switch Position	Voltage Selection	Cable Selection	Table Size	Reduction Ratio	Travel Distance
Code	Specification	PHOTOERCUIC SWITCH POSITION	Voltage Selection	Cable Selection	(mm)	(Degrees/Revolution)	(°)
RCGAB	6050		N(No)	N(No)		1.01414	±8.5
	6075	L(Motor Left Side)	A(Fenghua Driver)	2(2m Long Cable)	60×60	0.70303	±5.5
	60100	R(Motor Right Side)	B(Mingzhi Driver)	4(4m Long Cable)	60×60	0.538	±5
	60125		Detailed Driver Parameters: See table below	① Connector Type: HRS-12P Connector		0.43571	±4

- When using your own cables, please utilize the HR10A-10P-12S(73)(HRS) 12-pin socket connector.
 Sensors: NPN open-circuit output, home + limit, sensor voltage 24V, with a current draw below 8mA.
 Grounding wire is required to avoid static interference.
- Production Ratio: It refers to the rotational angle of the tabletop per one full rotation of the motor.
- The displacement stage operates with low-voltage signals. When routed alongside high-voltage cables, there may be signal interference. It is imperative to implement shielding measures.

 Divior Parameter Table.

Model		Motor	Rotation Center Height	Repeatability (Positioning Accuracy)	Load Capacity	Weight
Code	Specification	IVIOLOI	(mm)	(°)	(kgf)	(kg)
	6050		50±0.2			
RCGAB	6075	Two-Phase Stepper	75±0.2	±0.005	5	0.5
RCGAB	60100	Motor Specifications	100±0.2	±0.005	5	0.5
	60125		125±0.2			

Driver i arameter rable					
Driver	A (Fenghua Driver)	B(Mingzhi Driver)			
Voltage	DC12-40V	DC12-48V			
Drive Current	0.5-2.6 A/phase	0.3-2.2 A/phase			
Subdivision	16 speed	16 speed			